







21




23



24




20




25



27



26



B



SERVICE TOOL

1	3771	Torque wrench 30 Nm
2	3772	Open ended insert tool 27 mm with holder inset tool
3	3119	Bits 6 mm, length 40 mm
4	3773	Torque wrench set. Inkl. 3771, 3772, 3119
5	2883	Bits 6 mm, length 30 mm (For old type of yoke)
6	3774	Bits holder for Yoke
	8510	Allen wrench 1,27 mm
7	2706	Allen wrench 1,5 mm
	3761	Allen wrench 4 mm
8*	2714	Allen wrench 3 mm
	1246	Allen wrench 5 mm
	2275	Allen wrench 6 mm
9*	1354	Open end wrench I - 13 mm
	1388	Open end wrench 14 - 15 mm
	1312	Open end wrench 16 - 17 mm
10*	2893	Screw driver 3,5 mm
	2885	Screw driver 8,5 mm
11	2297	O-rings remover
12	2299	Drift for low pressure valve
13	3138	Holder for 2299
14	1304	Awl
15	3605	Combination tool no 1
16	3606	Combination tool no 2
	3875	Tool No. 3605 and 3606 in a box
17	2705	Adjusting tool
18	2894	Test fixture for low pressure valve
19	2150	Plastic band pliers
20	2112	Assembly tool
21	3397-10	Fixture for first stages
22	2587	Grease silicone 10 g
	8507	Grease Gleitmo 594 10 g
23	3139	Oil silicon 20 g
24	3460	Regulator test
25	3879	Toolkit:
	3717	Assembly drift A
	3757	Assembly fixture B
26	3758	Assembly fixture
27	3601	Dismounting tool for Triton

*Accessories

3873	Toolkit for Triton 2nd Stage:
8510	Allen wrench 1,27 mm
3601	Dismounting tool
3758	Assembly fixture